# KanazawaAZ CL5 Default fw2.0.4

| SNAKE | DANTE in/out | | Ch/Bus | NAME | MIC | Mute/R.Safe |
|---|---|---|---|---|---|---|
| 24A-1 | 3224-1 in | (DANTE-1) | 1 | | | Mute1 |
| 24A-2 | 3224-2 in | (DANTE-2) | 2 | | | Mute1 |
| 24A-3 | 3224-3 in | (DANTE-3) | 3 | O/H.L | C391 | Mute1 |
| 24A-4 | 3224-4 in | (DANTE-4) | 4 | O/H.R | C391 | Mute1 |
| 24A-5 | 3224-5 in | (DANTE-5) | 5 | F.tom | e904 | Mute1 |
| 24A-6 | 3224-6 in | (DANTE-6) | 6 | L.tom | e904 | Mute1 |
| 24A-7 | 3224-7 in | (DANTE-7) | 7 | H.tom | e904 | Mute1 |
| 24A-8 | 3224-8 in | (DANTE-8) | 8 | H/Hat | C451 | Mute1 |
| 24A-9 | 3224-9 in | (DANTE-9) | 9 | Sn.top | SM57 | Mute1 |
| 24A-10 | 3224-10 in | (DANTE-10) | 10 | Sn.bottom | SM57 | Mute1 |
| 24A-11 | 3224-11 in | (DANTE-11) | 11 | Kick.in | Beta91A | Mute1 |
| 24A-12 | 3224-12 in | (DANTE-12) | 12 | Kick.out | Beta52 | Mute1 |
| 24A-13 | 3224-13 in | (DANTE-13) | 13 | Bass.line | T-85 | Mute1 |
| 24A-14 | 3224-14 in | (DANTE-14) | 14 | Bass.mic | SM58 | Mute1 |
| 24A-15 | 3224-15 in | (DANTE-15) | 15 | SR.Gtr | SM57 | Mute1 |
| 24A-16 | 3224-16 in | (DANTE-16) | 16 | SL.Gtr | SM57 | Mute1 |
| 24A-17 | 3224-17 in | (DANTE-17) | 17 | | | Mute1 |
| 24A-18 | 3224-18 in | (DANTE-18) | 18 | | | Mute1 |
| 24A-19 | 3224-19 in | (DANTE-19) | 19 | | | Mute1 |
| 24A-20 | 3224-20 in | (DANTE-20) | 20 | | | Mute1 |
| 24A-21 | 3224-21 in | (DANTE-21) | 21 | | | Mute1 |
| 24A-22 | 3224-22 in | (DANTE-22) | 22 | | | Mute1 |
| 24A-23 | 3224-23 in | (DANTE-23) | 23 | | | Mute1 |
| 24A-24 | 3224-24 in | (DANTE-24) | 24 | | | Mute1 |
| 8-1 | 3224-25 in | (DANTE-25) | 25 | Voc | SM58 | Mute1 |
| 8-2 | 3224-26 in | (DANTE-26) | 26 | Voc.F/B | ch25 para | Mute1 |
| 8-3 | 3224-27 in | (DANTE-27) | 27 | Cho.SR | SM58 | Mute1 |
| 8-4 | 3224-28 in | (DANTE-28) | 28 | Cho.SL | SM58 | Mute1 |
| 8-5 | 3224-29 in | (DANTE-29) | 29 | Cho.Dr | SM58 | Mute1 |
| 8-6 | 3224-30 in | (DANTE-30) | 30 | | | Mute1 |
| 8-7 | 3224-31 in | (DANTE-31) | 31 | | | Mute1 |
| 8-8 | 3224-32 in | (DANTE-32) | 32 | SPARE | SM58 | Mute1 |
| 24B-1 | 1608-1 in | (DANTE-33) | 33 | | | Mute1 |
| 24B-2 | 1608-2 in | (DANTE-34) | 34 | | | Mute1 |
| 24B-3 | 1608-3 in | (DANTE-35) | 35 | | | Mute1 |
| 24B-4 | 1608-4 in | (DANTE-36) | 36 | | | Mute1 |
| 24B-5 | 1608-5 in | (DANTE-37) | 37 | | | |
| 24B-6 | 1608-6 in | (DANTE-38) | 38 | | | |
| | 1608-7 in | (DANTE-39) | 39 | AUD.L | SM57 | Recall.Safe |
| | 1608-8 in | (DANTE-40) | 40 | AUD.R | SM57 | Recall.Safe |
| | 1608-9 in | (DANTE-41) | 41 | CD.L | | Recall.Safe |
| | 1608-10 in | (DANTE-42) | 42 | CD.R | | Recall.Safe |
| | 1608-11 in | (DANTE-43) | 43 | CDMD.L | | Recall.Safe |
| | 1608-12 in | (DANTE-44) | 44 | CDMD.R | | Recall.Safe |
| | 1608-13 in | (DANTE-45) | 45 | DVD.L | | Recall.Safe |
| | 1608-14 in | (DANTE-46) | 46 | DVD.R | | Recall.Safe |
| | 1608-15 in | (DANTE-47) | 47 | i-Pod.L | | Recall.Safe |
| | 1608-16 in | (DANTE-48) | 48 | i-Pod.R | | Recall.Safe |
| | | | | | | |
| | | | | | | |
| | | | | | | |
| | | | | | | |
| | | | | | | |
| 24B-22 | 1608-2 out | (DANTE-26) | Mix.6 | IEM | | |
| 24B-23 | 1608-3 out | (DANTE-27) | Mix.7 | ST-IEM.L | | |
| 24B-24 | 1608-4 out | (DANTE-28) | Mix.8 | ST-IEM.R | | |
| | | | 49 | | | |
| | | | 50 | | | |
| | | | 51 | | | |
| | | | 52 | | | |
| | | | 53 | | | |
| | | | 54 | | | |
| | | | 55 | | | |
| | | | 56 | | | |
| | | | 57 | | | |
| | | | 58 | | | |
| | | | 59 | | | |
| | | | 60 | | | |
| | | | 61 | | | |
| | | | 62 | | | |
| | | | 63 | | | |
| | | | 64 | | | |
| | | | 65 | | | Recall.Safe |
| | | | 66 | | | Recall.Safe |
| | | | 67 | | | Recall.Safe |
| | | | 68 | | | Recall.Safe |
| | | | 69 | | | Recall.Safe |
| | OMNI-7 in | | 70 | MC.1 | | Recall.Safe |
| | OMNI-8 in | | 71 | MC.2 | | Recall.Safe |
| | OMNI-1 in | | 72 | TB | SM58S | Recall.Safe |

| SNAKE | DANTE in/out | Ch | NAME | | Mute/R.Safe |
|---|---|---|---|---|---|
| | OMNI-2 in | ST.in-1 | D-TWO | | |
| | OMNI-3.4 in | ST.in-2 | SPX2000↑ | | |
| | OMNI-5.6 in | ST.in-3 | SPX2000↓ | | |
| | EFF-RACK-4 | ST.in-4 | Dist | | |
| | EFF-RACK-5 | ST.in-5 | DDL | | |
| | EFF-RACK-6 | ST.in-6 | Rev.1 | | |
| | EFF-RACK-7 | ST.in-7 | Rev.2 | | |
| | EFF-RACK-8 | ST.in-8 | Rev.3 | | |

| SNAKE | DANTE in/out | | Bus | NAME | INSERT | |
|---|---|---|---|---|---|---|
| | | | ST.L/R | | to MTRX 1/2/3/4/5/6(Pre) | |
| | | | ST.L/R | | to MTRX 7/8(Post) | |
| | | | | | | |
| | 3224-1 out | (DANTE-1) | Mix.1 | Center | GEQ-RACK.1 | FM1502×2 |
| | 3224-2 out | (DANTE-2) | Mix.2 | SR | GEQ-RACK.2 | FM1502 |
| | 3224-3 out | (DANTE-3) | Mix.3 | SL | GEQ-RACK.3 | FM1502 |
| | 3224-4 out | (DANTE-4) | Mix.4 | Dr | GEQ-RACK.4 | FM1502 |
| | 3224-5 out | (DANTE-5) | Mix.5 | | GEQ-RACK.5 | FM1502 |
| 24B-22 | 1608-2 out | (DANTE-26) | Mix.6 | IEM | GEQ-RACK.6 | |
| 24B-23 | 1608-3 out | (DANTE-27) | Mix.7 | ST-IEM.L | GEQ-RACK.7 | |
| 24B-24 | 1608-4 out | (DANTE-28) | Mix.8 | ST-IEM.R | GEQ-RACK.8 | |
| | OMNI-1 out | | Mix.9 | D-TWO | | |
| | OMNI-2 out | | Mix.10 | SPX2000↑ | | |
| | OMNI-3 out | | Mix.11 | SPX2000↓ | | |
| | EFF-RACK-4 | | Mix.12 | DDL | | |
| | EFF-RACK-5 | | Mix.13 | Dist | | |
| | EFF-RACK-6 | | Mix.14 | Rev.1 | | |
| | EFF-RACK-7 | | Mix.15 | Rev.2 | | |
| | EFF-RACK-8 | | Mix.16 | Rev.3 | | |
| | | | Mix.17 | | | |
| | | | Mix.18 | | | |
| | | | Mix.19 | | | |
| | | | Mix.20 | | | |
| | | | Mix.21 | | | |
| | | | Mix.22 | | | |
| | | | Mix.23 | | | |
| | | | Mix.24 | | | |
| | | | | | | |
| | | | Matrix 1 | Rec | | |
| | | | Matrix 2 | Rec | | |
| | OMNI-7 out | | Matrix 3 | Rec.L | | |
| | OMNI-8 out | | Matrix 4 | Rec.R | | |
| | 1608-5 out | (DANTE-29) | Matrix 5 | Rec CD-R.L | | CD-RW |
| | 1608-6 out | (DANTE-30) | Matrix 6 | Rec CD.R.R | | CD-RW |
| | 1608-7 out | (DANTE-31) | Matrix 7 | House.L | GEQ-RACK.9 | DN360 |
| | 1608-8 out | (DANTE-32) | Matrix 8 | House.R | GEQ-RACK.10 | DN360 |

24A.Snake = ステージ奥Box→Rio3224-D(下手AMP.Rack上)
8ch.Snake = ステージ上手Box→ステージ下手Box→Rio3224-D(下手AMP.Rack上)
24B.Snake = ステージ奥Box→Rio1608-D(PA席)

## Nuendo Live Input (48×48 48kHz 24bit)

| PC input | DANTE | | PC input | DANTE | | |
|---|---|---|---|---|---|---|
| 1 | 3224-1 in | | 25 | 3224-25 in | Voc | |
| 2 | 3224-2 in | | 26 | 3224-26 in | Voc.F/B | |
| 3 | 3224-3 in | O/H.L | 27 | 3224-27 in | Cho.SR | |
| 4 | 3224-4 in | O/H.R | 28 | 3224-28 in | Cho.SL | |
| 5 | 3224-5 in | F.tom | 29 | 3224-29 in | Cho.Dr | |
| 6 | 3224-6 in | L.tom | 30 | 3224-30 in | | |
| 7 | 3224-7 in | H.tom | 31 | 3224-31 in | | |
| 8 | 3224-8 in | H/Hat | 32 | 3224-32 in | SPARE | |
| 9 | 3224-9 in | Sn.top | 33 | 1608-1 in | | |
| 10 | 3224-10 in | Sn.bottom | 34 | 1608-2 in | | |
| 11 | 3224-11 in | Kick.in | 35 | 1608-3 in | | |
| 12 | 3224-12 in | Kick.out | 36 | 1608-4 in | | |
| 13 | 3224-13 in | Bass.line | 37 | 1608-5 out | PAout.L | |
| 14 | 3224-14 in | Bass.mic | 38 | 1608-6 out | PAout.R | |
| 15 | 3224-15 in | SR.Gtr | 39 | 1608-7 in | AUD.L | |
| 16 | 3224-16 in | SL.Gtr | 40 | 1608-8 in | AUD.R | |
| 17 | 3224-17 in | | 41 | 1608-9 in | CD.L | |
| 18 | 3224-18 in | | 42 | 1608-10 in | CD.R | |
| 19 | 3224-19 in | | 43 | 1608-11 in | CDMD.L | |
| 20 | 3224-20 in | | 44 | 1608-12 in | CDMD.R | |
| 21 | 3224-21 in | | 45 | 1608-13 in | DVD.L | |
| 22 | 3224-22 in | | 46 | 1608-14 in | DVD.R | |
| 23 | 3224-23 in | | 47 | 1608-15 in | i-Pod.L | |
| 24 | 3224-24 in | | 48 | 1608-16 in | i-Pod.R | |